


# TH-T-718 Twin Hammer Bucket Type Air Screw Driver



PART NO.	Description	Q'ty	PART NO.	Description	Q'ty	PART NO.	Description	Q'ty
TH-P-718-01-104-03	ROTOR BLADE	6	TH-P-718-13-700-03	SCREW	1	TH-P-718-38-504-08	CYLINDER	1
TH-P-718-02-200-04	O-RING (P4x1.9)	1	TH-P-718-14-701-01	OIL SEAL	1	TH-P-718-39-504-01	BOLT	1
TH-P-718-02-201-03	O-RING (P11x1.5)	1	TH-P-718-14-702-01	OIL SEAL	1	TH-P-718-40-703-03	HAMMER	2
TH-P-718-02-201-05	O-RING (P11x2.4)	1	TH-P-718-15-702-04	BALL BEARING (R6)	2	TH-P-718-41-704-02	HAMMER CASE	1
TH-P-718-02-201-10	O-RING (P15.5x1.5)	1	TH-P-718-17-302-01	SWITCH LEVER	1	TH-P-718-43-703-01	HAMMER CAM	1
TH-P-718-03-700-04	STEEL BALL ( $\phi$ 4mm)	2	TH-P-718-18-702-01	REVERSE VALVE	1	TH-P-718-51-701-03	BUSHING	1
TH-P-718-03-700-07	STEEL BALL ( $\phi$ 3.175mm)	1	TH-P-718-19-702-01	SPEED SWITCH	1	TH-P-718-51-703-03	BUSHING	1
TH-P-718-04-700-03	PIN ( $\phi$ 2x6)	2	TH-P-718-21-703-01	WASHER	1	TH-P-718-51-802-01	BUSHING	1
TH-P-718-04-702-04	PIN ( $\phi$ 3x24)	2	TH-P-718-24-705-02	VALVE ROD	1	TH-P-718-52-501-02	WASHER	1
TH-P-718-05-701-05	PIN ( $\phi$ 2x14)	1	TH-P-718-25-702-08	AIR INLET (PT)	1	TH-P-718-52-701-07	WASHER	1
TH-P-718-06-700-01	SPRING	1	TH-P-718-26-703-06	MUFFLER	1	TH-P-718-54-702-01	RING	1
TH-P-718-06-701-04	SPRING	1	TH-P-718-31-703-01	HOOK	1	TH-P-718-74-707-16	ANVIL	1
TH-P-718-06-701-07	SPRING	1	TH-P-718-31-705-01	HOOK	1	TH-P-718-75-606-02	FRONT CAP	1
TH-P-718-12-701-07	RETAINING RING	1	TH-P-718-35-708-07	ROTOR	1	TH-P-718-79-609-06	HANDLE	1
TH-P-718-13-401-01	SCREW	1	TH-P-718-36-503-18	FRONT PLATE	1			
TH-P-718-13-700-02	SCREW	1	TH-P-718-37-503-05	REAR PLATE	1			

--If you need to order parts, please mark both Parts NO. and Description.--